


Ready... Set... Install!

WiFi Your Way™ Home

What's inside

The following instructions will take you through all the steps necessary to get your Breezeline WiFi Your Way™ Home up and running.



Before you begin

Follow these important steps to ensure a successful installation of WiFi Your Way™ Home.

- 1. You should have received an email from **accounts@plume.com** please click the verification link within that email to verify your account.
- 2. Confirm your Breezeline gateway is installed and online.
 - Visit breezeline.com/self-install-gateway for helpful gateway installation directions.
- **3.** Confirm your mobile device is connected to your gateway WiFi using the network name and password located on the label of your gateway.
- **4.** Download the "WiFi Your Way™ Home" mobile app from your device's app store.





5. Open the app and tap "Sign In" and follow the on-screen directions.

3

Extender Installation

- 1. Identify the optimal location to plug in your WiFi extender to maximize coverage. Select a location away from your gateway and not too close to large furniture, mirrors, glass, or metal. If your device has a power cord, plug one side into the back of the extender and the other side into a power outlet. If not, plug your pod directly into a wall outlet.
- 2. To verify your network setup, in the WiFi Your Way™ Home app on the home screen scroll to the Adapt section and tap "View network". You should see at least two connected WiFi points which means your extender is connected and was successfully added to your WiFi network.

NOTE: If you do not see any connections or you are adding additional extenders, please stand near the plugged-in extender and tap the three dots in the upper right hand corner of the Network screen to "Add a pod" and follow the on-screen instructions.

PRO INSTALLATION TIPS:

- Enable app notifications
- WiFi Extender Placement
- Each extender will cover 2-4 rooms
- Plug your WiFi extenders into interior wall outlets
- Place extenders far away from your gateway to extend WiFi coverage
- Set up profiles for family members to manage their WiFi access.
- To change your network name or password, click the gear wheel at the top of the "Adapt" section of the app home screen and then tap the pencil or 3 dots to edit.



Need additional support?

For more information and support on WiFi Your Way™ Home, scan the QR Code or visit **breezeline.com/support**.